## **NEC IPK II Conferencing.**

## **CONFERENCING CALLS FROM A DIGITAL HANDSET:**

To conference calls from a digital handset follow the following procedure:

- 1. Answer or make the first call
- 2. Press the Conf key
- 3. Make the next call (either internal extension number or **0** then outside number) or retrieve call from Hold. If calling wait for called party to answer.
- 4. Press **Conf** key <u>twice</u> to establish conference.
- 5. To add more calls press **Conf** key, make another call then press **Conf** key <u>twice</u>.

If any party wishes to exit from a conference they should just hang up.

To remove someone from a conference press **Hold** key and hang up. Calls will ring back in sequence. Answer calls and put them on hold and hang up on the unwanted caller then reestablish the conference as per above instructions.

To split or alternate between callers in a conference, press **Conf** key and dial **794**. Repeat this to alternate between the callers in the conference. To return to the conference press the **Conf** key twice.

## CONFERENCING CALLS FROM AN ANALOGUE HANDSET (INCLUDING POLYCOM UNITS):

To conference calls from an analogue handset follow the following procedure:

- 1 Answer or make the first call
- 2 Press the **recall or flash** key (on the Polycom unit it is the key that has a picture of multiple people on it) then dial **# 1**
- 3 Make the next call (either internal extension number or **0** then outside number) wait for called party to answer.
- 4 Press the **recall** key <u>twice</u> to establish conference.
- 5 To add more calls press the **recall** key, make another call then press the **recall** key <u>twice</u> to establish the conference.